



HOW TO REPLACE THE CARTRIDGE

You can replace the cartridge yourself, so **DO NOT RETURN THE STATICMASTER®** to the factory. Many distributors stock the replacement cartridges, but if unavailable, please contact the factory.

The cartridge of the 1-inch model is attached to the handle with a single screw. Loosen the screw to remove the old cartridge, and attach the new cartridge using the same screw, as illustrated.

The 3-inch cartridge is attached by tabs on either side of the handle. To remove the cartridge, push in on one tab and lift the cartridge away from the handle as illustrated. To install the new cartridge, engage the tab and slot on one side, then press together while aligning the tab and slot on the other side.



Staticmaster® is distributed in accordance with the provisions of USNRC License 31-28397-01E and is manufactured pursuant to NY State Dept. of Health Radioactive Materials License C1391. It complies with manufacturing, testing, and labelling requirements of these licenses. The end user is exempt from any licensing requirements in accordance with 10 CFR 30.15.

CAUTION

For your protection, Polonium 210 is sealed between a base of silver and a layer of gold. A final gold plating provides additional integrity. This results in a foil that is insoluble and inert in most materials. The foil is protected by a metal grid which prevents direct contact with the active surface. These protective procedures eliminate hazards to the user that could result if unsealed Po-210 was inhaled or taken into the body.

You should, however, be careful to observe the following precautions. Do not remove the protective grid or touch the metal foil under the grid. If the foil is accidentally handled, wash hands thoroughly before eating. Keep away from children or persons who are unable to observe these simple precautions.

NRD LLC
2937 Alt Blvd, Grand Island, NY 14072
Phone (716) 773-7634 / Toll Free (800) 525-8076 / Fax (716) 773-7744
www.nrdllc.com